


# MODEL 220011X92A

# HOUSING ASSEMBLY

KEY NO.	DESCRIPTION	PART NO.
1	Engine ‡	_____
2	Housing	776022
3	Height Adjuster, Left Rear (7" Wheels)	672637
4	Knob	071495
5	Wheel and Tire	042172
6	Locknut, Flange	015x84
7	Bolt, Carriage	002x81
9	Bolt, Engine	0025x6
10	Nut	015x68
11	Height Adjuster, Left Front (7" Wheels)	672635
12	Washer, Belleville	17x137
13	Washer	17x124
14	Bolt, Hex	01x142
15	Blade, Side Discharge	042225E701
16	Adapter, Blade	071056
17	Height Adjuster, Right Front (7" Wheels)	672634
18	Height Adjuster, Right Rear (7" Wheels)	672636
19	Guard, Rear	672738
20	Screw	26x245
21	Deflector, Chute	672421
22	Push-On Cap	028x42
23	Pin, Pivot	215x11 Z
24	Spring	0166x5
27	Bracket, Left Handle	1101303E700
28	Bracket, Right Handle	1101302E700
--	Parts Bag Assembly	1101638
--	Book, Instruction	F-040400L

\* For information on Replacement Parts for this engine contact the manufacturer.



KEY NO.	DESCRIPTION	PART NO.
1	Handle, Upper (Black)	1101556E701
2	Handle, Lower (Black)	071137E701
3	Bolt	002x77
4	Knob, Plastic	071294
7	Locknut	15x116
12	Guide, Rope	071530
13	Engine Stop Lever	043653E701
14	Bracket, Stop Lever	1101454
15	Fastener, Cable	1101353
16	Engine Stop Cable	672840