




Illustrated Parts List

8000 Watt Portable Generator


Model 030471-0



Briggs & Stratton Power Products GROUP, LLC
Milwaukee, Wisconsin, U.S.A.

This generator is rated in accordance with CSA (Canadian Standards Association) standard C22.2 No. 100-04 (motors and generators).

Exploded View - Main Unit




Copyright © 2010 Briggs & Stratton Power Products Group, LLC. All rights reserved. No part of this material may be reproduced or transmitted in any form without the express written permission of Briggs & Stratton Power Products Group, LLC.

Parts List - Main Unit

Item	Part #	Description	Item	Part #	Description
1	312007GS	CRADLE	44	311478GS	DECAL
2	312008GS	GRIP-HANDLE	45	311988GS	TANK-FUEL
3	312009GS	GRIP-HANDLE	46	311990GS	CAP-FUEL
4	75477GS	SCREW	47	209939GS	SEAL
5	311480GS	DECAL	48	311991GS	FILTER-SCREEN
6	311479GS	DECAL	49	312040GS	WIRE
7	197798GS	DECAL	50	311992GS	GAUGE-FUEL
8	311482GS	DECAL	51	87680GS	NUT
9	200310GS	DECAL	52	209421GS	BOLT
10	B4986GS	DECAL	53	312005GS	WASHER
11	200311GS	DECAL	54	312006GS	GROMMET
12	312020GS	HEATSHIELD	55	312010GS	SPACER
13	312019GS	HEATSHIELD	56	209417GS	VALVE-FUEL
14	209775GS	BOLT	57	791745	KIT - FUEL HOSE (cut to fit)
15	193043GS	BATTERY	58	197896GS	SCREW
16	312014GS	CABLE-BTTRY, RED	59	47411GS	SCREW
17	312026GS	CABLE-BTTRY, BLACK	60	22097GS	WASHER
18	311983GS	PLATE-BATTERY	61	188333GS	DECAL
19	312045GS	WASHER	62	202997GS	DECAL
20	192569GS	MUFFLER	63	194984GS	DECAL
21	83083GS	SCREEN	900	§	ENGINE
22	197861GS	NUT	Parts Not Illustrated		
23	311987GS	SCREW	193347GS	KIT-HARDWARE BATTERY	
24	67989GS	NUT	310784GS	MANUAL-OPERATOR	
25	311985GS	SUPPORT-MUFFLER	B4177GS	CHARGER-BATTERY	
27	193747GS	NUT	§ - Contact Engine Manufacturer		
28	22129GS	WASHER			
29	45771GS	NUT			
30	312012GS	MOUNT-VIBRATION			
31	207824GS	SCREW			
32	209428GS	END COVER			
33	312038GS	VOLTAGE REGULATOR			
34	312041GS	TERMINAL BLOCK			
35	312638GS	BOLT			
36	312639GS	BOLT			
37	209441GS	BRUSH ASSY			
38	312640GS	BOLT			
39	49226GS	WASHER			
40	209423GS	CARRIER-BEARING			
41	312032GS	STATOR			
42	312029GS	ROTOR			
43	207878GS	NUT			

Exploded View & Parts List - Control Panel




Item	Part #	Description
1	312001GS	PANEL-CONTROL
2	312002GS	BOX-CONTROL PANEL
3	312030GS	COVER-OUTLET
4	312031GS	COVER-OUTLET
5	198245GS	METER-HOUR
6	692318	KEY-SWITCH IGNITION
7	202033GS	BREAKER-CIRCUIT 30A
8	43437GS	OUTLET-120/240V TL30A
9	68759GS	OUTLET-120V 20A
10	312034GS	CABLE-CHOKE
11	202394GS	BREAKER-CIRCUIT 20A
12	312004GS	JACK-COAXIAL
13	311565GS	DECAL
14	209775GS	BOLT
15	312033GS	TRIM-EDGE
16	311476GS	DECAL
17	312003GS	RELAY
18	312027GS	RECTIFIER-BRIDGE

Part Not Illustrated
691959

KEY

Exploded View & Parts List - Wheel Kit



Item	Part #	Description	Item	Part #	Description
1	311999GS	HANDLE	12	192310GS	MOUNT-VIBRATION
2	311998GS	GRIP-HANDLE	13	52857GS	NUT
3	312000GS	GRIP-HANDLE	14	42568GS	BOLT
4	75477GS	SCREW	15	311994GS	SUPPORT-LEG
5	312013GS	BOLT	16	46526GS	WASHER
6	187104GS	WASHER	17	45772GS	NUT
7	49820GS	NUT	18	94856GS	WASHER
8	207825GS	BOLT	19	312022GS	HUBCAP
9	312016GS	KNOB	20	312021GS	WHEEL
10	312015GS	SPRING	21	5025210YP	PIN-HAIR .0915 x 1-7/8
11	312017GS	PIN	22	312023GS	AXLE