



Illustrated Parts List

Model Series

12G600

TYPE NUMBERS
0100 through 0110.

TABLE OF CONTENTS

Air Cleaner	5
Blower Housing/Shrouds	6
Camshaft	2
Carburetor	4
Controls	5
Crankshaft	2
Cylinder	2
Cylinder Head	3
Engine Sump	2
Exhaust System	5
Flywheel	6
Fuel Supply	4
Governor Spring	5
Ignition	5
Lubrication	2
Piston Group	2
Rewind Starter	6

Not for reproduction



PRINTED IN U.S.A.

COPYRIGHT by BRIGGS & STRATTON CORPORATION
All rights reserved. No part of this material may be reproduced or transmitted, in any form or by any means, electronic or mechanical, including photocopying, recording or by any information storage and retrieval system, without permission in writing from Briggs & Stratton Corporation.


12G600






1319 WARNING LABEL






REQUIRED when replacing parts with warning labels affixed.

1019 LABEL KIT




Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.










Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
5376-4 Assemblies include all parts shown in frames. **11/17/2008**



Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
 5376-5 Assemblies include all parts shown in frames. 11/17/2008

12G600

1036 EMISSIONS LABEL



Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
5376-6 Assemblies include all parts shown in frames. 11/17/2008

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1	697893	Cylinder Assembly	25	795429	Piston Assembly (Standard) (Used After Code Date 07090300).	27	691866	Lock-Piston Pin
2	399269	Kit-Bushing/Seal (Magneto Side)				28	499423	Pin-Piston
3	★299819S	Seal-Oil (Magneto Side)				29	499424	Rod-Connecting
4	493279	Sump-Engine				32	691664	Screw (Connecting Rod)
		----- Note -----				32A	695759	Screw (Connecting Rod)
		498983 Sump-Engine Used on Type No(s). 0110.				33	499642	Valve-Exhaust
5	795501	Head-Cylinder (Used After Code Date 05110100).				34	499641	Valve-Intake
		----- Note -----				35	691304	Spring-Valve (Intake)
		695276 Head-Cylinder (Used Before Code Date 05110200).				36	691304	Spring-Valve (Exhaust)
7	★Δ697230	Gasket-Cylinder Head				37	694086	Guard-Flywheel
8	495786	Breather Assembly				40	692194	Retainer-Valve
9	★699833	Gasket-Breather				43	691486	Slinger-Governor/Oil
10	691125	Screw (Breather Assembly)	26	795431	Ring Set (Standard) (Used After Code Date 07090300).			----- Note -----
11	499675	Tube-Breather						691997 Slinger-Governor/Oil
12	★692232	Gasket-Crankcase						Used on Type No(s). 0110.
13	691137	Screw (Cylinder Head)				45	690977	Tappet-Valve
15	691680	Plug-Oil Drain (Square Socket)				46	694039	Camshaft
16	692803	Crankshaft				51	★♦♦Δ692668	Gasket-Intake
		----- Note -----				51A	★♦♦Δ697735	Gasket-Intake
		691457 Crankshaft Used on Type No(s). 0110.				51B	★♦♦Δ692555	Gasket-Intake
20	★399781S	Seal-Oil (PTO Side)				55	691421	Housing-Rewind Starter
22	691092	Screw (Crankcase Cover/Sump)				58	697316	Rope-Starter (Cut To Required Length)
23	697610	Flywheel				60	281434S	Grip-Starter Rope
		----- Note -----				65	690837	Screw (Rewind Starter)
		697586 Flywheel Used on Type No(s). 0110.				78	691108	Screw (Flywheel Guard)
24	222698S	Key-Flywheel				95	691636	Screw (Throttle Valve)
						97	499682	Shaft-Throttle
						98	398185	Kit-Idle Speed
						104	●691242	Pin-Float Hinge
						108	692567	Valve-Choke
						109	693866	Shaft-Choke

★ Included in Engine Gasket Set-Ref. No.358.

● Included in Carburetor Overhaul Kit-Ref. No. 121.

♦ Included in Carburetor Gasket Set-Ref. No. 977.

Δ Included in Valve Gasket Set-Ref. No 1095.

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

12G600

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
117A	498976	Jet–Main (Standard)	222A	792402	Bracket–Control (Used After Code Date 05110100).	334	691061	Screw (Magneto Armature)
118A	694975	Jet–Main (High Altitude)			----- Note -----	337	692051	Plug–Spark
121	792383	Kit–Carburetor Overhaul			693378 Bracket– Control	341	690368	Stud (Mounting Bracket)
122	692799	Spacer–Carburetor			(Used Before Code Date 05110200).	347	691396	Switch–Rocker
122A	792382	Spacer–Carburetor				356	692390	Wire–Stop
125A	698953	Carburetor	222B	792396	Bracket–Control (Used After Code Date 05110100).	356A	693010	Wire–Stop
127	694468	Plug–Welch			----- Note -----	358	792384	Gasket Set–Engine
130	691181	Valve–Throttle			693897 Bracket– Control	363	19069	Puller–Flywheel
127A	691739	Plug–Welch			(Used Before Code Date 05110200).	365	691129	Screw (Carburetor)
133	398187	Float–Carburetor						(Used After Code Date 05110100).
134	398188	Kit–Needle/Seat			----- Note -----			691136 Screw (Carburetor)
137	693981	Gasket–Float Bowl						(Used Before Code Date 05110200).
146	690979	Key–Timing	227	691467	Lever–Governor Control			Wrench–Spark Plug
163A	692667	Gasket–Air Cleaner				238	691300	Cap–Valve
187	791766	Line–Fuel (Cut to Required Length)				265	690798	Clamp–Casing
188	691147	Screw (Control Bracket)				267	691044	Screw (Casing Clamp)
190	690940	Screw (Fuel Tank)				268	691025	Casing–Control Wire (Cut To Required Length)
192	694543	Adjuster–Rocker Arm				269	691026	Wire–Control (Cut To Required Length)
202	691303	Link–Mechanical Governor	270	691027	Nut (Control Wire Casing)	443	691637	Screw (Air Cleaner Primer Base)
209	693032	Spring–Governor ----- Note ----- 691290 Spring– Governor Used on Type No(s). 0110.	271	691028	Lever–Control	443A	692523	Screw (Air Cleaner Primer Base)
			276	271716	Washer–Sealing	445	491588S	Filter–Air Cleaner Cartridge
			287	690940	Screw (Dipstick Tube)	455	791960	Cup–Flywheel
			300	697590	Muffler–Exhaust	456	692299	Plate–Pawl Friction
			304	499676	Housing–Blower	459	281505S	Ratchet–Pawl
			305	691108	Screw (Blower Housing)	472	693809	Knob–Choke Bracket
			306	691232	Shield–Cylinder	493	692877	Bracket–Mounting
			307	690345	Screw (Cylinder Shield)	505	691251	Nut (Governor Control Lever)
			332	690662	Nut (Flywheel)	523	499621	Dipstick
			333	802574	Armature–Magneto	524	692296	Seal–Dipstick Tube
						525	495265	Tube–Dipstick

★ Included in Engine Gasket Set–Ref. No.358.

● Included in Carburetor Overhaul Kit–Ref. No. 121.

◆ Included in Carburetor Gasket Set–Ref. No. 977.

△ Included in Valve Gasket Set–Ref. No 1095.

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
529A	691923	Grommet	684	690345	Screw (Breather Passage Cover)	930A	692675	Guard-Rewind
532	692851	Nut (Mounting Bracket)	689	691855	Spring-Friction	957	692046	Cap-Fuel Tank (Plastic)
562	691119	Bolt (Governor-Control Lever)	692	690572	Spring-Detent	957B	699985	Cap-Fuel Tank (Plastic)
564A	693808	Screw (Control Cover)	718	690959	Pin-Locating	966A	693863	Base-Air Cleaner Primer (Choke System)
584	697734	Cover-Breather Passage	741	794388	Gear-Timing (Use Without Woodruff Key)	968	692298	Cover-Air Cleaner
585	★691879	Gasket-Breather Passage			(Used After Code Date 07093000). ----- Note -----	972	699374	Tank-Fuel (Plastic)
592	690800	Nut (Rewind Starter)		790345	Gear-Timing (Use Without Woodruff Key)	975	493640	Bowl-Float
597	691696	Screw (Pawl Friction Plate)			(Used Before Code Date 07100100).	977	792385	Gasket Set-Carburetor
601	791850	Clamp-Hose		691830	Gear-Timing (Uses Woodruff Key)	993	★△694088	Gasket-Cylinder Head Plate
604A	693807	Cover-Control	830	694544	Stud-Rocker Arm	1005	691346	Fan-Flywheel
608	497680	Starter-Rewind	832	691466	Guard-Muffler	1019	695247	Kit-Label
613	691108	Screw (Muffler)	836	691147	Screw (Muffler Guard)	1022	★△691890	Gasket-Rocker Cover
613A	691140	Screw (Muffler)	836A	697551	Screw (Muffler Guard)	1023	499624	Cover-Rocker Arm
615	690340	Retainer-Governor Shaft	842	★691031	Seal-O Ring (Dipstick Tube)	1026	692045	Rod-Push
616	698801	Crank-Governor	843	692310	Sleeve-Lever	1029	691230	Arm-Rocker
619	691108	Screw (Cylinder Head Plate)	847	692047	Dipstick/Tube Assembly	1034	691343	Guide-Push Rod Label-Emissions (Available From A Briggs & Statton Authorized Dealer)
621	692310	Switch-Stop	851	493880S	Terminal-Spark Plug	1036		
633	◆693867	Seal-Choke/Throttle Shaft	868	★△692044	Seal-Valve	1058	277102	Operator's Manual
633A	◆691321	Seal-Choke/Throttle Shaft	883	★△691893	Gasket-Exhaust	1059	692311	Kit-Screw/Washer
635	66538S	Boot-Spark Plug	886	696268	Gasket Set-Cylinder Head/Plate	1095	792386	Gasket Set-Valve
670	692294	Spacer-Fuel Tank	914	691108	Screw (Rocker Cover)	1102	691255	Pilot-Guide
						1210	498144	Pulley/Spring Assembly (Pulley)
						1211	498144	Pulley/Spring Assembly (Spring)
						1319	794467	Label-Warning
						1330	272147	Manual-Repair

★ Included in Engine Gasket Set-Ref. No.358.

● Included in Carburetor Overhaul Kit-Ref. No. 121.

◆ Included in Carburetor Gasket Set-Ref. No. 977.

△ Included in Valve Gasket Set-Ref. No 1095.

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

Not for
Reproduction

Not for
Reproduction

Not for
Reproduction

