


GENERAC[®]
Portable Products



WheelHouse[™]
5550
RATED WATTS

PORTABLE GENERATOR

Illustrated Parts List




Questions? Help is just a moment away!


Call: **Generac Generator Helpline - 1-800-270-1408** M-F 8-5 CT

Web: www.generac-portables.com or www.briggsandstratton.com

Model No. 1646-3 (5,550 Watt AC Generator) Manual No. 193711A Revision I (12/02/2004)

EXPLODED VIEW - MAIN UNIT





WheelHouse™ 5550 Watt Generator



PARTS LIST – MAIN UNIT

Item	Part #	Description
1	M189457GS	FRAME
2	194150GS	KIT,Vibration Mount 45°
4	190220GS	HOUSING, Engine Adapter
5	NSP	ASSY,Alternator (see page 5)
6	194151GS	KIT, Hrdwr Mounting Adptr
8	96796GS	WASHER, M8 Flat
10	190274BGS	SBHCS, 3/8-16 x 1.0 Lg.
11	187365FGS	HHCS, 5/16-24 x 7.44
14	194729GS	KIT, Muffler Brkt w/ Hardware
15	695398	GASKET, Exhaust
17	189008GS	MUFFLER
18	*	SHCS, 5/16 - 18 x 3/4"
19	83083GS	SCREEN, Spark Arrest
20	B4986GS	DECAL, Ground
21	194153GS	KIT,Vibration Mount
22	86494GS	SCREW,Wing M6 - 1.0 x 16
23	86292GS	SCREW, 10 - 16 x 3/4, Self Drill
24	192793GS	SHIELD, Heat
25	191190GS	CAP
26	74908GS	SCREW, M5-0.8 x 10 Taptite
28	*	WASHER, Flat 1/2
31	77816GS	DECAL, Hot Muffler
34	195422GS	COVER, Rear Bearing Carrier
35	194432GS	KIT, Hose Fuel w/ Clamps
37	192376GS	SCREW, 12 - 24 x 1/2 THD Forming
40	189114GS	KNOB, Fuel Tank Hold Down
41	192980GS	KIT,Valve Tank
44	196181GS	ASSY,Tank, Fuel (Includes Items 41, 50, 51 & 52)
45	189420GS	CAP, Fuel Gauge


Item	Part #	Description
46	B4135GS	PIN, with Lanyard
48	195373GS	WIRE, Ground
50	188333GS	DECAL, Fuel Tank
51	194799GS	DECAL, Danger
52	189235GS	DECAL, Start Instructions
53	192125GS	KIT, Pushnut, 1/2"
54	193548GS	KIT,Wheel (Includes Item 53)
55	73054GS	DECAL, Shut-Off, Fuel
56	M188205GS	HANDLE
57	189456GS	KIT, Handle Fastening
58	190355GS	ASSY, Control Panel (see page 4)
59	*	NUT, Palnut 3/16"
60	189117GS	QUICK CONNECT, Fuel, 1/4 Barb
61	192695GS	QUICK CONNECT, Fuel, 1/4 Barb
63	192553GS	KIT,Vibe Mount
65	189332GS	CAP PLUG, 1 - 1/4" O.D.
72	192480GS	DECAL, Warning, Fuel Line Disconnect
900	§	ENGINE

Items Not Illustrated


BB3061GS	BOTTLE, Oil
43438GS	PLUG, 250V, 30A
MS5242	MANUAL, Engine
193711GS	MANUAL, Owners
189208GS	STABILIZER, Fuel
193821GS	KIT, Decal, Service

* - Items without part numbers are common fasteners and are available at your local hardware store.

§ - Contact Engine Manufacturer




EXPLODED VIEW AND PARTS LIST – CONTROL PANEL



Item	Part #	Description
1	195112GS	KIT, Control Panel Lid
2	188889GS	CONTROL PANEL, Compact
6	68759GS	OUTLET, 120V, 20A, Duplex
7	*	NUT, Palnut, Pushnut, 5/32
8	84198GS	CAP, Breaker, Circuit
9	75207GS	BREAKER, Circuit
10	43437GS	OUTLET, 120/240 Locking, 30A
11	*	NUT, Palnut, Pushnut, 3/16
12	*	SCREW, Phillips, Head 3.5 x 18
13	93857GS	BAR, Retaining
14	188890GS	COVER, Back, Control Panel
15	*	SCREW, Self Tapping, STC 3 x 18
16	22694GS	HOUSING, Receptacle
17	*	SCREW, Phillips, 3.5 x 14

* - Items without part numbers are common fasteners and are available at your local hardware store.




WheelHouse™ 5550 Watt Generator

GENERAC®
Portable Products

by **Briggs & Stratton®**
POWER PRODUCTS

EXPLODED VIEW AND PARTS LIST – ALTERNATOR



Item	Part #	Description
1	186059GS	ADAPTER, Mounting, Alternator
2	190032GS	ROTOR
3	190079AGS	STATOR
4	186060GS	RBC, with O-Ring (p/n 189197GS)
5	86308HGS	HHCS, M6 - 1.0 x 140 SEMS
6	91825GS	ASSY, Holder, Rectifier/Brush
7	66849GS	TAPTITE, M5 - 0.8 x 16
8	22694GS	RECEPTACLE, 6 pin
9	81917GS	PIN, Roll, 4mm x 10
10	193428AGS	ASSY, Wire, Ground
13	190356GS	HARNESS, Wire, Power